



SEM TRAINERS & SYSTEMS

WHERE TIME MOVES AHEAD TO KEEP PACE WITH KNOWLEDGE

SEM- Scientific Educative Methods in Science, Engineering & Medicine

Mobile : +91 88495 63724

Mobile 1: +91 98791 03905

Email: sem@semtrainers.com

Website: www.semtrainers.com

Arrhythmia Television Interface

Item No. 1018150 [W49429]
Dimensions 0.001 x 0.001 x 0.001 cm
MPN: ADI-10

[Read More](#)

SKU:

Categories: Auscultation



Product Description

In classroom situations, where no ECG-monitor is available, this Arrhythmia Television Interface (ATI) allows connection of the Arrhythmia Tutor (W49007) to a conventional television monitor. The selected arrhythmia rhythms will be displayed on the monitor, additionally it is also possible to freeze the action or to add ECG grid lines. The unit is supplied with power cords, NTSC television connector cable, video connector cable, and a three-lead cable. The unit is suitable for 115 Volt. (For countries with 230 Volt, a transformer unit, which can be locally purchased, is necessary). Please be sure your television is capable to receive the NTSC signal. PAL televisions can only be adapted if they contain a video inlet (CINCH) in which the video connector cable can be plugged.